


GROUP:	5520AB
FORM:	4678-1087
FILE:	Alternator Parts List Section
DATE:	October, 1987

PRODUCTS COVERED

MODEL	VOLTS	AMPS
5520AB	28	180



Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	36499	1	Nut, 1/2-20 Hex. Lock	23	36604	1	Rotor Assy.
2	3249	1	Washer, Shaft	24	36605	1	Bearing, Ball #205 PP
3	13943	4	Screw, 8-32	25	38052	1	Housing, D.E.
4	Not Used			26	95933	1	Holder & Block Assy.
5	Not Used			27	71262	2	Block, Drive
6	95934	1	Fan	28	71261	1	Shaft & Cam Assy., Spilne
7	13762	1	Key, #2 Woodruff	29	38056	1	Plate, Cover
8	3322	3	Screw, 8-32 x 3/8 Fl. Hd.	30	36325	6	Lockwasher, Tabbed
9	21656	1	Retainer, Bearing	31	5584	16	Lockwasher, #6
10	28441	1	Bearing, Ball 204PP	32	36324	12	Screw, 6-32 x 3/8 Hex. Hd.
11	5579	4	Screw, 8-32 x 7/8 Fl Hd.	33	30873	1	Ring, Snap
12	59831	1	Housing, S.R. End	34	54291	12	Screw, 1/4-20 x 3/4 Soc. Hd. Cap.
13	30848	1	Retainer, Bearing	35	2523	12	Lockwasher, 1/4
14	36610	1	Rigging Assy., Brush	36	30872	1	Key
15	100487	1	Connector Assy.	37	6810	5	Screw, #6 Drive
16	2435	8	Lockwasher, #8	38	35949	4	Brush
17	7273	2	Screw, 8-32 x 1/2 Fl. Hd.	39	6812	2	Lockwasher, Tabbed
18	7984	2	Screw, 8-32 x 7/8 Fl. Hd.	40	2434	7	Lockwasher #10
19	59832	1	Cover, Terminal	41	36817	7	Screw, 10-32 x 2 1/2 Soc. Hd. Cap
20	100489	1	Stator Assy.	42	Not Used		
21	59870	1	Shroud, Air	43	100480	1	Conn. & Jump. Assy. (Incl. #15)
22	38724	1	Slip Ring	44	2525	2	Nut, 8-32 Hex. Br.

Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at [www.prestolite.com](http://www.prestolite.com), or contact our customer service department at: